

Work Permit # DRL-2012-04 Work Order # ____ Job# ____ Activity# ____

Nork requester fills out this section.	☐ Standir	ng Work Permit		, <u> </u>					
Requester: Don Lynch	Date: 03/08/2012	Ext.: 2253	PHENIX						
Other Contact person (if different from	requester): Carter Biggs		Ext.: 7515	1					
Work Control Coordinator: Don Lynch	ำ	Start Date: 03/12/2012							
Brief Description of Work: Trouble sho	on of Work: Trouble shoot FVTX and VTX thermal and coolant leak problems								
Building: 1008	Room: IR	Equipment: VTX/FVTX	Service Provider: PHI	ENIX techs					
CC, Requester/Designee, Service Pro	vider, and ES&H (as necessary) fil	Il out this section or attach anal	ysis						
ES&H ANALYSIS									
	None ☐ Activation	Airborne	☐ Contamination	⊠Radiation					
		☐Moisture Density Gauges	Soil Density Gauges	☐X-ray Equipment					
☐ Special nuclear materials involve	red, notify Isotope Special Materials	Group	☐ Fissionable materials inv	ved, notify Laboratory Criticality Officer					
Safety Concerns	None	☐ Ergonomics	☐ Transport of Haz/Rad Ma	aterial					
☐ Adding/Removing Walls or Roof	fs Confined Space*	☐ Explosives	☐ Lead*	☐ Penetrating Fire Walls					
Adding/Removing Walls of Roof	☐ Corrosive	☐ Flammable		☐ Pressurized Systems					
☐ Asbestos*	☐ Cryogenic	☐ Fumes/Mist/Dust*		☐ Rigging/Critical Lift					
☐ Beryllium*	☐ Electrical	☐ Heat/Cold Stress	☐ Noise*	☐ Toxic Materials*					
☐ Biohazard*		☐ Hydraulic	☐ Non-ionizing Radiation*	☐ Vacuum					
☐ Chemicals*	☐ Excavation	☐ Lasers*	☐ Oxygen Deficiency*	Other					
* Does this work require medical clear	arance or surveillance from the Occu	upational Medicine Clinic? 🔲 Ye	∌s ⊠ No						
Environmental Concerns		None	☐ Work impacts Environmental Permit No.						
☐ Atmospheric Discharges (rad/no	on-rad)	☐ Land Use	Soil	☐ Waste-Mixed					
_ ' ' '	<u> </u>	☐ Liquid Discharges	Activation/contamination Waste-Clean	☐ Waste-Radioactive					
Chemical or Rad Material Storage	ge or use	☐ Ciduld Discharges ☐ Oil/PCB							
Cesspools (UIC)		Management	☐ Waste-Hazardous	☐ Waste-Regulated Medical					
☐ High water/power consumption		☐ Spill potential	☐ Waste-Industrial	☐ Underground Duct/Piping					
Waste disposition by:				Other					
Pollution Prevention (P2)/Waste M	Inimization Opportunity:	None Yes							
FACILITY CONCERNS	⊠ None								
A A A A A A A A A A A A A A A A A A A	☐ Electrical Noise	☐ Potential to Cause a F	alse Alarm	☐ Vibrations					
Access/Egress Limitations	☐ Impacts Facility Use A	Agreement	☐ Temperature Change	☐ Other					
☐ Configuration Control	☐ Maintenance Work on	Ventilation Systems	Utility Interruptions						
WORK CONTROLS	•								
Work Practices									
None	☐ Exhaust Ventilation		☐ Spill Containment	☐ Security (see Instruction Sheet)					
☐ Back-up Person/Watch	☐ HP Coverage	Posting/Warning Signs	☐ Time Limitation	☐ Other					
Barricades	☐ IH Survey	Scaffolding-requires inspection	n level")						
Protective Equipment	•								
None	☐ Ear Plugs	Gloves	☐ Lab Coat						
☐ Coveralls	☐ Ear Muffs	Goggles	Respirator	☐ Safety Harness					
☐ Disposable Clothing	☐ Face Shield	☐ Hard Hat	☐ Shoe Covers	⊠ Safety ☐ Other					
_ '				Shoes					
Permits Required (Permits must be			2 1						
None	Cutting/Welding		Impair Fire Protection Systems						
Concrete/Masonry Penetration	☐ Digging/Core Drilling		Rad Work Permit-RWP No						
Confined Space Entry	☐ Electrical Working Hot	t Other							
Dosimetry/Monitoring									
None	☐ Heat Stress Monitor	Real Time Monitor	☐ TLD						
☐ Air Effluent	☐ Noise Survey/Dosime	Dosimeter	☐ Waste Characterization						
Ground Water	O ₂ /Combustible Gas	Self-reading Digital	Other Check O2 level prior to entry						
☐ Liquid Effluent	☐ Passive Vapor Monito	Sorbent Tube/Filter Pump							
Training Requirements (List below specific training requirements) CA -Collider User, PHENIX Awareness, Working at heights									
									Based on analysis above, the Wal ratings below:
ES&H Risk Level:	☐ Low ☐ Modera	ate High	WCC:	Date:					
Complexity Level:		ate High	Service Provider:	Date:					
Work Coordination:		ate High	Authorization to start	Date:					
			(Departmental Sup/WCC/Des	signed)					

J. DU	til work requester and service provide	ei communu	te to work plair (use alla	Chillents for detaile	u piaris)							
	See attached work plan											
	Special Working Conditions Required: None Operational Limits Imposed: Modification work limited to lower octants easily reachable when standing on lower magnet superstructure.											
	Post Work Testing Required: No											
	Job Safety Analysis Required: Ye	es 🖾 No			Walkdown Required: ⊠ Yes □ No							
		Traintomit toquitor. Ex 100 El 110										
	Reviewed by: Primary Reviewer will determine the size of the review team and the other signatures required based on hazards and job complexity. Primary Reviewer signature me that the hazards and risks that could impact ES&H have been identified and will be controlled according to BNL requirements.											
	<u>Title</u>	Name ((print)	<u>Signature</u>		Life #		<u>Date</u>				
	Primary Reviewer											
	ES&H Professional											
	Other											
	Other											
	Work Control Coordinator	Don Ly	nch			20146						
	Service Provider											
		Review	Done: in series	☐ team								
4 1-1	e eite manne en el fill en taleir en etiem	•		•								
4. JO	b site personnel fill out this section. Note: Signature indicates personnel p	erforming w	ork have read and under	stand the hazards	and permit require	ements (including any	, attachments)					
	Job Supervisor:			010110 110 11020100	Contractor Supervisor:							
	Workers:		Life#:	Workers :		Life#:						
	Workers are encouraged to provide fe	edback on F	S&H concerns or on idea	as for improved job	work flow Use f	eedback form or space	ce below					
	-					oodbaan romm or opac						
5. De	partmental Job Supervisor, Work Con											
	Conditions are appropriate to start wor		controls are in plac		y for job.)							
	Name:		Signature:		Life#:		Date:					
6. De	partmental Job Supervisor, Work Req	uester/Des	ignee determines if Pos	st Job Review is r	equired. 🗌 Yes	s 🗌 No						
	Post Job Review (Fill in names of review	ewers)										
	Name:		Signature:		Life#:		Date:					
	Name:		Signature:		Life#:		Date:					
7. Wo	orker provides feedback.											
	Worker Feedback (use attached sheet a) WCM/WCC: Is any feedback requ											
	b) Workers: Are there better methods	s or safer wa	ays to perform this job in t	the future? \(\square\) Ye	es 🗌 No							
	seout: Work Control Coordinator (au up of work area to work supervisor)	thorizing d	ept.) checks quality of c	ompleted permit	and ensures the	work site is left in a	n acceptable	condition. (WCC can delegate				
	Name:		Signature:		Life#:		Date:					
	Comments:											

1.18/3k11e011.doc 2 (9/2004)

FVTX & VTX Trouble Shooting

Introduction

This procedure is prepared to document the steps necessary to make minor changes to the VTX/FVTX coolant flow distribution, trouble shooting to isolate and repair a internal small coolant leak, trouble shoot thermal problems and add 4 aluminum chill plates to the exterior of the FVTX/VTX assemblies, 1 each on the noth and south end of the east and west detector halves. (Note: the chill plates may not be installed pending results of the troubleshooting efforts).

The tasks described above are worker planned work and do not require a specific procedure, except the following procedure to prepare the FVTX/VTX subsystem for warm up prior to separating the detector halves.

Procedure

NOTE: all work is to be performed only by appropriately trained PHENIX technicians.

- A) The following is the procedure to be followed to warm up the system.
 - 1) At ~6 AM confirm with the Shift Crew that the VTX/FVTX systems are off.
 - 2) Once confirmed, set chiller 1 to 5C (chiller one is on the left closest to the shield wall. It is labeled). It is currently set to 0C (or lower). It should be left there for an hour to warm up on its own.
 - 3) An hour later (\sim 7am), the set-point of chiller 1 should be set to 10C.
 - 4) At ~8am, the plug door will open and access to the CM central region will be provided by moving the EC and/or WC.
 - 5) Before the FVTX/VTX halves can be separated, the temp of the system should be confirmed to be at 10C.
 - 6) Once detector is ready to be separated, the chiller set-points should be set to 20°C. Once this is done, the power to the chillers (both 1 and 2) should be turned OFF. This will drop the pressure in the system to zero. Changing the set-point to 20°C before turning off is done so that when the chillers are powered back on, the compressors do not try to cool the fluid right away.
- B) Carefully separate the 2 halves to their open position ~ 10 inches from the beampipe, taking care to avoid any contact with detector surfaces. This is worker planned work to be performed only by PHENIX technicians approved by PHENIX engineering.

At this point PHENIX technicians and FVTX/VTX experts shall perform the tasks described above, taking care to minimize the time that the halves are separated and installing covers when possible. After all tasks have been acceptably completed proceed to the next step.

C) Remove the covers and carefully close the 2 halves to their run position tightly around the beampipe, taking care to avoid any contact with detector surfaces and to completely seal the detector. This is worker

planned work to be performed only by PHENIX technicians approved by PHENIX engineering.

- D) Once the halves are together and we are ready to flow Novec, the follow steps should be followed to turn the cooling system back ON:
 - 1) Put the system into Bypass. To do this, open the bypass valve first, then close the feed and return valves slowly.
 - 2) Once in bypass, turn the chiller back on and note the temp of both systems. Set the set-point of the chillers to that temperature this way we are only circulating fluid and not cooling it.

The next step is to pressurize the detector and look for any new leaks that may have developed. There are 4 loops in the cooling system:

VTX/FVTX North, VTX/FVTX South, Big Wheel North, Big Wheel South. (note, the VTX pixels are on the Big Wheel loops)

- 3) To test a loop, open one of the feed valves slowly to pressurize one of the manifolds. Note, the bypass valves should still be open. Check the manifold for leaks. At the same time, carefully look at the detector for leaks. If that loop is fine, open both the feed valve and return valve completely then close the bypass valve slowly.
- 4-6) Repeat step3 for the other 3 loops.
- 7) Once all 4 loops are running, recheck the connections for leaks since the systems pressure will double once all the bypass valves are closed.

Please note, the detector should be closed and flowing N2 for at least an hour before bringing chiller 1 temp below 10C.

- 8) Once all loops are pressurized and tested, the system can commence cooling. The set-points of the chillers can be dropped by ~5C per hour until chiller 1 is at 0C and Chiller 2 is at 10C.
- 9) Once at operating temps, the manifolds and detector should be checked for leaks again in case something happened during the temperature cycle. The connections inside of chiller 1 and chiller 2 should also be inspected to make sure no leaks have developed again.
- 10) Final step is to make note in the chiller log book of the levels of the Novec so that losses can be monitored overnight.

After completing the above, note any difficulties or "lessons learned" on the work permit accompanying this procedure and close out this work permit.

